


IMPORTANT MANUAL

Do Not Throw Away

Poulan PRO



REPAIR PARTS MANUAL

MODEL:

PBGT26H54
GARDEN TRACTOR


ALWAYS WEAR EYE PROTECTION DURING OPERATION

Visit our website: www.poulan-pro.com

⚠ WARNING:

Read this Manual and follow all Warnings and Safety Instructions. Failure to do so can result in serious injury.


**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
DECALS**



KEY NO.	PART NO.	DESCRIPTION
1	411658	Decal, Operator's
2	402355	Decal, Hood RH
3	402525	Decal, Dash Lower
4	411140	Decal, Replacement
5	172743	Decal, Strg Whl
6	408843	Decal, Engine HP
8	198785	Decal, Mower Sch.
9	145005	Decal, Battery Dnge/Poi
10	402357	Decal, Hood LH
11	178502	Decal, Mower Caution

KEY NO.	PART NO.	DESCRIPTION
12	170563	Decal, Mower Warning Keep Hand Away
13	172740	Decal, Fender
14	408796	Decal, Panel SD
15	408948	Decal, Fender SD LH
16	408949	Decal, Fender SD RH
--	166960	Decal, Bypass
--	193279X428	Pad, Footrest, LH
--	193101X428	Pad, Footrest, RH
--	409631	Manual, Operator's (Eng & French)
--	417307	Manual, Parts

WHEELS AND TIRES





KEY NO.	PART NO.	DESCRIPTION
1	59192	Cap, Valve, Tire
2	65139	Stem, Valve
3	106228X421	Rim Assembly, Front
4	8134H	Tube, Front (Service Item Only)
5	106230X	Tire, Front
6	278H	Fitting, Grease (Front Wheel Only)
7	9040H	Bearing, Flange (Front Wheel Only)
8	104757X421	Cap, Axle (Front Wheel Only)
9	105588X	Tire, Rear
10	7154J	Tube, Rear (Service Item Only)
11	124074X421	Rim Assembly, Rear
--	144334	Sealant, Tire (10 oz. Tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm


TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40

SCHEMATIC

SCH12



IGNITION SWITCH




WIRING INSULATED CLIPS
NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
ELECTRICAL**




**TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
ELECTRICAL**

KEY NO.	PART NO.	DESCRIPTION
1	144927	Battery
2	74760412	Bolt Hex Head 1/4-20 x 3/4
8	186491	Box Battery
16	176138	Switch Interlock Push-In
21	175688	Harness Socket Light W/4152J
22	4152J	Bulb Light
24	400253	Cable Battery
25	198893	Cable Start Red 17.5"
26	175158	Fuse
27	73510400	Nut Keps Hex 1/4-20 unc
28	145491	Cable, Ground
29	401545	Switch, Seat
30	193350	Switch, Ignition
33	411935	Key/Chain
34	110712X	Switch Light / Reset
40	401104	Harness Ign. Dash
41	17720408	Screw Thd Cut 1/4-20 x 1/2
42	131563	Cover, Terminal
43	192507	Solenoid
46	401763	Gauge Hourmeter
50	174653	Switch, PTO
55	17060512	Screw Thdrol 5/16-18 x 3/4 TYTT
59	400303	Outlet 12-Volt
71	194276	Harness Ignition, Chassis
79	175242	Bulbholder Asm. Incan Descent
90	400724	Cover Terminal Battery
91	190270	Strap Battery Mount Front
99	17670412	Screw Hexwsh Thdrol 1/4-20 x 3/4
100	19091416	Washer 9/32 x 7/8 x 16 Ga.
101	198317	Pigtail MATNLK
102	404454	Harness Pigtail K46
103	407962	Harness Pigtail 12V Outlet

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
CHASSIS




chassis-tex_Stealth II PL_1

**TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
CHASSIS**

KEY NO.	PART NO.	DESCRIPTION
5	195102X428	Dash
14	175260X428	Hood
18	175289X428	Grille
34	196125	Plate Engine
36	17060512	Screw 5/16-18 x 3/4
37	400009X428	Fender
58	194314	Bracket Fender
68	17490508	Screw Thdrol 5/16-18 x 1/2
122	192512	Screw WSHD Hex 10-32 x 5/8
130	191611	Screw 10 x 3/4 Single Lead-Hex
139	196539	Bolt Shoulder
148	164655	Bumper
150	175351	Duct Heat Hood
152	199535	Shield Browning/Debris
153	161840	Lens Bar
161	193097X428	Console Fuel Window
162	142432	Screw Hex Wsh Hi-Lo 1/4 x 1/2
165	196826	Bracket Support Tank
175	193236	Crossmember
176	400776	Screw #10-24 x 5/8 Rnd Qudrx
177	195227	Bushing Steering
178	195651	Cargo Asm. Net
180	195477	Chassis
181	193102X428	Bushing Mtg. Fender Crgo.
182	192551	Dash Lower
183	74780520	Bolt Fin Hex 5/16-18 UNC x 1-1/4
189	17000512	Screw 5/16-18 x 3/4
194	73900500	Nut Lock Hex Flange 5/16-18
196	193098X428	Console Asm. Deck Lift
198	197300X505	Indicator Deck Lift
199	196377	Plate Deck Lift
205	169847X428	Skirt Hood RH
206	169848X428	Skirt Hood LH
222	137729	Screw Thd Roll 1/4-20 x 5/8
228	195161	Stud Fastener
235	406129	Spacer Fender
236	73930500	Nut Center Lock 5/16-18 UNC
278	196394	Bracket Pickoff Hood

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
DRIVE**




**TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
DRIVE**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle, TuffTorq K66	167	405257	Latch Brake Parking
2	7070E	Key	170	194322	Keeper Belt Centerspan
3	7563R	Hardened Washer	171	72110616	Bolt
7	199837	Hub Asm. Wheel	183	197357	Spacer Axle
9	140080	Bolt Hub Wheel	184	195361X505	Handle Parking Brake
15	19131316	Washer 13/32 x 13/16 x 16 Ga.	185	72110620	Bolt
17	401072	Spring, Brake	186	194321	Spacer Retainer
26	199679	Spring Return Cruise	187	19133210	Washer
29	407245	Rod, Brake	188	194323	Link Clutch Ground Drive
33	12000053	Ring E	189	194317	Bellcrank Ground Drive
35	197275	Rod, Brake, Park	190	194318	Keeper Bellcrank Ground Drive
42	8883R	Cover, Foot Pedal	196	17000616	Screw 3/8-16 x 1
49	72110614	Bolt	197	199769	Bracket Clutch Anti-Rotation
50	194327	Pulley Idler Flat	206	197867	Bracket Mount Latch Cruise
51	73900600	Lock Nut 3/8-16	207	197868	Latch Control Cruise
52	194326	Idler V-Groove 910" Offset	208	197869	Bolt Sector Control Cruise
56	125907X	V-Belt, Drive	209	199466	Rod Control Cruise
64	197865	Shaft Asm. Pedal Brake Control	210	197860	Rocker Asm. Pedal Control
69	123800X	Washer 1 1/32 x 1 5/8 x 16 Ga.	211	120183X	Bearing Nylon
73	74490544	Bolt Hex Flghd 5/16-18 Gr 5	213	195352X428	Knob Control Cruise
74	142432	Screw Hx Wsh Hi-Lo 1/4 x 1/2 unc	214	197302X428	Pad Pedal Forward
80	407182	Strap Torque	215	197301X428	Pad Pedal Reverse
92	74760520	Bolt Fin Hex 5/16-18 unc x 1.25	216	196131	Bracket Pulley Idler
99	407247	Rod Bypass	221	403187	Retainer Spring Clip Handle
116	73900500	Nut Lock Hex Flange 5/16-18	222	79212010	Washer 21/32 x 1-1/4 x 10 Ga.
125	17000512	Screw 5/16-18 x 3/4	224	193099X428	Console Toolbox
143	17490508	Screw 5/16-18 x 1/2	225	407311	Keeper Belt Trans.
153	4497H	Retainer Spring	226	407109	Bracket Mount Torque
159	76020412	Pin Cotter 1/8 x 3/4			
160	169484	Retainer Clip			
161	195403	Spring, Return, Clutch			
163	407246	Rod Pedal Control			
166	197290	Nut Push .625			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
STEERING ASSEMBLY**




**TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
STEERING ASSEMBLY**

KEY NO.	PART NO.	DESCRIPTION
1	186093X428	Wheel, Steering
2	195968	Axle Asm., Front
4	403089	Spindle Asm., LH
5	403090	Spindle Asm., RH
6	6266H	Bearing, Race Thrust Harden
7	121748X	Washer 25/32 x 1-5/8 x 16 Ga.
8	12000029	Ring, Klip #T5304-75
9	121232X	Cap, Spindle
13	121749X	Washer 25/32 x 1-1/4 x 16 Ga.
14	10040600	Washer, Lock Hvy Hlcl Spr 3/8
15	73540600	Nut, Crown Lock 3/8-24 unf
16	408219	Shaft Steering
19	194729	Plate Steering
20	195626X428	Boot, Steering
21	186737	Adapter, Wheel Steering
22	194845	Bushing, Strg. Blk
26	186095X428	Insert, Wheel Steering
28	17000612	Screw 3/8-16 x 3/4
35	194732	Gear, Sector Plate
45	19183812	Washer 9/16 x 2-3/8 x 12 Ga.
51	73940800	Nut Hex Jam Toplock 1/2-20 unf
53	188967	Washer Hardened .793 x 1.637 x .060
57	197246	Bracket Upstop
58	194747	Bolt Shoulder Sector Pivot CFM
59	194748	Washer Thrust Sector Steering
60	73971000	Nut Flange Lock 5/8-11
61	194740	Draglink LH
62	194741	Draglink, RH
63	17000512	Screw 5/16-18 x 3/4
64	199849	Retainer Clip Spring Steering
66	71020748	Bolt Hex Fghd 7/16-14 x 3 Serr
67	194737	Bushing PM Front Axle
68	73900700	Nut Lock Flange 7/16-14 Gr. 5
69	199162	Washer 1.5 x .505 x .118
70	196197	Bracket Deck Susp. Front

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
ENGINE**



SPARK ARRESTER KIT

engine-tex_bs-2cyl_2

TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40 ENGINE


KEY NO.	PART NO.	DESCRIPTION
1	-----	Engine B&S Model No. 445877-0760-E1
2	149723	Muffler
9	194320	Keeper Belt Engine
11	179335	Clutch Electric
12	194343	Pulley Engine
15	193499	Tank Fuel 4.0
18	195951	Cap Asm
20	175437X428	Control Throttle
21	191611	Screw 10 x 3/4 Single Lead-Hex
22	187767X428	Control Choke
28	401135	Fuel Line
29	137180	Spark Arrester Kit
31	145006	Clip Push-In Hinged
37	123487X	Clamp Hose
41	126197X	Washer 1-1/2 OD x 15/32 ID x .250
42	10040700	Washer Lock 7/16
45	73510400	Nut Keps Hex 1/4-20 unc
62	146629	Shield Heat Muffler
69	165391	Gasket
70	159955	Tube Exhaust LH
71	160589	Tube Exhaust RH
79	183906	Screw Socket Head
81	148456	Tube Drain Oil Easy
82	181654	Plug Drain Oil
84	17060620	Screw 3/8-16 x 1-1/4
85	179953	Bolt Hex 7/16-20 x 3.75 Gr. 5
87	198239	Bolt 5/16-18 unc x 1 w/Sems
90	17000616	Screw 3/8-16 x 1
91	187495	Bushing 1.375 OD

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Engine Power Rating Information

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J11940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-5). Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net horsepower). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
MOWER DECK**




**TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
MOWER DECK**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	195632X421	Deck Weldment Mower	50	72110616	Bolt Rdhd Sqnk 3/8-16 unc x 2
6	196066	Cover Mandrel LH	52	196106	Pulley Idler Clutching
7	197181	Cover Mandrel RH	58	187342	Baffle Right
8	174365	Bolt 7/16 Asm. Blade	59	187344	Baffle Left
--	187255	Blade Mulching	60	187607	Baffle Center
--	187256	Blade Bagging	97	178515	Washer Hardened
12	400337	Rod Anti-Sway	98	196105	Spring Drive
13	187291	Shaft Asm. w/Lower Bearing	113	72110508	Bolt Rdhd Sqnk 5/16-18 x 3/4
14	187281	Housing, Mandrel	114	187556	Rod Tension Relief
15	110485X	Bearing, Ball, Mandrel	116	193406	Bolt, Shoulder
16	19131312	Washer 13/32 x 13/16 x 12 Ga.	117	174873	Gauge Wheel
17	72140505	Bolt Carr. 5/16-18 x 5/8	120	19132012	Washer 13/32 x 1-1/4 x 12 Ga.
19	194208	Pin Cotter 5/16 Bow Tie Lock	122	187557	Bushing Tension Relief
21	73680500	Nut, Crownlock 5/16-18 unc	185	73900700	Nut Lock Flange 7/16-14 Gr. 5
24	105304X	Cap Sleeve	187	195161	Stud Fastener w/"D" Anti-Rotation
25	178102	Spring, Torsion	188	73900500	Nut Lock Hex Flange 5/16-18
26	110452X	Nut, Push	189	195185	Arm Susp. Mower Rear
27	187257X428	Deflector Shield	190	196539	Bolt Shoulder
29	131491	Rod, Hinge	192	198468	Keeper Belt Idler
30	173984	Screw, Thdroll Washer Head	194	72140716	Bolt Carr Sqnk 3/8-16 x 2-1/4
31	187690	Washer, Spacer Mower Vented	195	72140620	Bolt Rdhd 3/8-16 unc x 2-3/4 Gr. 5
32	173436	Pulley, Mandrel	--	187292	Mandrel Asm. Service (Includes
33	400234	Nut, Flg. Top Lock	--	197701	Key Nos. 13-15 and 33)
34	73680600	Nut Crownlock 3/8-16 unc			Replacement Mower, Complete
39	197380	Pulley, Idler, Stationary			
43	196065	Arm, Idler			
46	137729	Screw, Thdroll. 1/4-20 x 5/8			
47	196103	V-Belt, Mower			
49	73900600	Nut, Lock Flg. 3/8-16 unc			

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

**TRACTOR - - MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40
SEAT ASSEMBLY**



seat-tex_6-tex LT


KEY NO.	PART NO.	DESCRIPTION
1	406623	Seat
2	180166	Bracket Pivot Fender
3	140675	Strap, Asm Fender
6	73800600	Nut, Lock W/Ins. 3/8-16 unc
7	124181X	Spring, Seat Cprsn
8	171877	Bolt 5/16-18 uncx 3/4 w/Sems
10	196977	Pan, Seat
21	171852	Bolt, Shoulder 5/16-18

KEY NO.	PART NO.	DESCRIPTION
37	73800500	Nut, Lock 5/16-18 unc
40	197661	Handle Slide Seat
41	198200	Spring Latch Seat
43	74760612	Bolt Fin Hex 3/8-16 unc x 3/4
44	19133812	Washer 13/32 x 2-3/8 x 12 Ga.

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR -- MODEL NUMBER PBGT26H54 (96042004002), PRODUCT NO. 960 42 00-40

MOWER LIFT




KEY NO.	PART NO.	DESCRIPTION
2	195223	Shaft Asm., Lift
3	195230	Lever Asm., Lift Rh
7	196492X421	Grip, Lever
10	196314	Spring Torsion
87	194209	Pin Cotter 7/16 Bow Tie Lock
88	195304	Spring Lift Assist
89	19191912	Washer Clear Zinc
90	194208	Pin Cotter 5/16 Bow Tie Lock

KEY NO.	PART NO.	DESCRIPTION
91	403407	Link Lift Susp Mower Rear
97	17000612	Screw 3/8-16 x .75
98	195264	Link Lift Susp. Front Mower

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

Poulan PRO

Poulain PRO




REMARQUE: Toutes les dimensions de composant sont données en pouces E.-U. -- 1 pouce = 25,4 mm

44 19133812 Ressort de compression
43 74760612 Ressort de l'ensemble de l'ailie
41 198200 Support de pivot
3 180166 Siège
3 140675 Attache de l'ensemble de l'ailie
6 73800600 Ecrou frein H avec insert 3/8-16 x 3/4
7 124181X Ressort de compression du siège
8 171877 Boulon 5/16-18 uncx 3/4
10 196977 Couverte du siège
21 171852 Boulon à épaulement 5/16-18 unc
37 73800600 Ecrou frein 5/16-18 unc
40 197661 Guidon

NO.	NO	DE	PIECE	DESCRIPTION
1	406623	REF.	PIECE	DESCRIPTION
2	180166	DE	DE	PIECE
3	140675	DE	DE	PIECE
6	73800600	NO.	NO	REF.
7	124181X			
8	171877			
10	196977			
21	171852			
37	73800600			
40	197661			


seat-tex_6-tex_LT



CARTER DE TONDEUSE

TRACTEUR - NO. DE MODÈLE PBT26H54 (96042004002), NO. DE PRODUIT 960 42 00-40

NO.	DE	DE	PIECE	DESCRIPTION
1	195632X421	Ensemble du carter		
2	196106	Pouille du galet-tendeur		
3	58	187342	Chicane C.D.	
4	59	187344	Chicane C.G.	
5	60	187607	Chicane Centrale	
6	7	187255	Lame déchiqueteuse	
7	8	187256	Lame pour boulrage	
8	9	197181	Couvercle de mandrin C.D.	
9	10	194365	Couvercle de mandrin C.G.	
10	11	4000337	Tige	
11	12	187291	Ensemble de l'arbre	
12	13	110485X	Carter du mandrin à billes	
13	14	19131312	Rondelle 13/32 x 1/32 x 12Ga.	
14	15	194208	Boulille Serrure 5/16	
15	16	73680500	Ecrou 5/16-18 unc	
16	17	110452X	Chapeau de mandrin	
17	18	178102	Ressort de torsion	
18	19	105304X	Ecrou	
19	20	73680500	Ecrou frein 7/16-14 Cat. 5	
20	21	73680500	Ecrou frein 7/16-14 Cat. 5	
21	22	122	Douille 187557	
22	23	120	Rondelle 13/32 x 1/32 x 12Ga.	
23	24	185	187557	
24	25	187	195161	
25	26	188	73900500	
26	27	189	195185	
27	28	190	196539	
28	29	192	198468	
29	30	194	72140716	
30	31	195	72140620	
31	32	197292	Ensemble de mandrin (y compris les	
32	33	--	197701	
33	34	--	nos. de ref. 13-15 Cat. 5	
34	35	73680600	Ensemble du carter de tonduseuse complet	
35	36	400234	Ecrou	
36	37	173436	Pouille de mandrin	
37	38	137729	Bras du galet-tendeur C.G.	
38	39	197380	Pouille du galet-tendeur C.G.	
39	40	446	Ecrou frein 3/8-16 unc	
40	41	196103	Ecrou de mandrin	
41	42	73900600	Ecrou frein 3/8-16 unc	
42	43	72110616	Boulion 3/8-16 x 2-3/4 Cat. 5	
43	44	72110508	Boulion 5/16-18 x 3/4	
44	45	116	193406	
45	46	114	187556	
46	47	113	1874873	
47	48	117	187557	
48	49	120	19132012	
49	50	122	Douille 187557	
50		125	Rondelle 13/32 x 1/32 x 12Ga.	




Le pouvoirs bruts évaluant pour les modèles de moteur de gaz individuels est conforme à la SAE (la Société d'ingénieurs Automotrices) le code J11940 (le Petit Pouvoir de Moteur à la Momen de torsion Evaluation La Procédure), et l'exécution de classement a été obtenue à la corrigée conformatement à SAE J1995 (la Révision 2002-5). Le véritable pouvoirs bruts sera plus bas est affiché par, entre autres choses, les conditions d'opération améliorées et le moteur-a-la-variabilité des moteurs. Donné les deux le tableau large de produits sur lesquels moteurs est étendue de grande valeur écologiques applicables à l'opération de l'équipement, le moteur de gaz ne développera pas la variété de problèmes ambiantes (la température, l'humidité, l'altitude), et le moteur-a-la-viabilité de moteur. En raison des limitations de fabrication, le refroidissement, le carburateur, la pompe de carburant, etc.), les limitations d'application, les conditions d'opération est en raison d'une association de facteurs inclus, mais pas limite à, les accessoires (le nettoyage d'air, l'échappement, charbon et caoutchouc dans un morceau donné d'équipement pour l'appliance (applicable, « surplace » ou nette). Cette différence est en raison d'une association de facteurs inclus, mais pas limite à, les accessoires (le nettoyage d'air, l'échappement, charbon et caoutchouc dans un morceau donné d'équipement pour l'appliance (applicable, « surplace » ou nette). Cette différence

Informations de Classement de Pouvoir de moteur

NO.	NO.	DE	DE	PIECE	DESCRIPTION
1	-----	-----	-----	-----	Moteur Briggs-No. de modèle 44587-
2	149723	Silencieux	Corrôle du moteur	179335	Embrayage électrique
9	194320	Corrôle du moteur	194343	179335	Embrayage électrique
11	194320	Corrôle du moteur	194343	179335	Embrayage électrique
12	194343	Pouille	193499	194343	Reservoir d'essence
15	195951	Chapéau	193499	194343	Reservoir d'essence
18	195951	Reservoir d'essence	193499	194343	Reservoir d'essence
20	175437X428	Commande des gaz	191611	175437X428	Commande du starter
21	191611	VIS H 10 X 3/4	187767X428	191611	Commande du starter
22	187767X428	Commande du starter	401135	191611	Commande des gaz
28	401135	Commande des gaz	137180	191611	Commande des gaz
29	137180	jeu de pare - éthincelle	145006	123487X	Bride de serrage de tuyau
31	145006	Collier presse	37	126197X	Rondelle 1-1/2 OD X 15/32 ID X .250
42	10040700	Rondelle frein 7/16	41	126197X	Rondelle 1-1/2 OD X 15/32 ID X .250
45	73510400	Ecrois H 1/4-20 unc	42	10040700	Rondelle frein 7/16
62	146629	Déflecteur de débris	45	73510400	Rondelle frein 7/16
69	165391	Graminure de silencieux	70	176067	Tube C.G.
70	176067	Tube C.G.	71	160589	Tube C.D.
71	160589	Tube C.D.	79	183906	VIS 5/16-18 X 1
79	183906	VIS 5/16-18 X 1	82	181654	Bouchon
84	1760620	VIS 3/8-16 X 1/4	84	179953	Boulon 7/16-20 X 20 X 3.75 Gr.5
85	179953	Boulon 7/16-20 X 20 X 3.75 Gr.5	87	198239	Boulon 5/16-18 unc X 1 avec sems
87	198239	Boulon 5/16-18 unc X 1 avec sems	90	17000616	VIS 3/8-16 X 1
91	187495	Bushing 1.375 OD	91	187495	VIS en pouces E.-U. --1 pouce = 25,4 mm

REMARQUE: Toutes les dimensions de composant sont don- nées en pouces E.-U. --1 pouce = 25,4 mm

ÉQUIPEMENT FACULTATIF
PARA-ETINCELLES




ENSEMBLE DE LA DIRECTION

TRACTEUR - NO. DE MODÈLE PBCGT26H54 (96042004002), NO. DE PRODUIT 960 42 00-40


NO.	DE	PIÈCE	DESCRIPTION
1	186093X428	Volant de direction	
2	195968	Essieu	
4	403089	Ensemble de la broche C.G.	
5	403090	Ensemble de la broche C.D.	
6	6266H	Palier de butée durci	
7	121748X	Rondelle 25/32 x 1-5/8 x 16 ja.	
8	12000029	Rondelle clip N°5304-75	
9	121232X	Chapeau de broche	
13	121749X	Rondelle 25/32 x 1-1/4 x 16 ja.	
14	10040600	Rondelle frein 3/8-24 unit	
15	73540600	Ecrou frein 3/8-24 unit	
16	408219	Arbre de direction	
19	194729	Arbre de plaque	
20	195626X428	Initialisation de direction	
21	186737	Adaptateur du volant de direction	
22	194845	Douille de direction	
26	186095X428	Insert de chapeau du volant de direction	
28	17000612	Vis 3/8-16 x 3/4	
35	194732	Section dentée	
45	19183812	Vis 3/8-16 x 2-3/8 x 12 ja.	
51	73940800	Contre-écrou 1/2-20 unit	
53	188967	Rondelle .793 x 1.637 x .060	
57	197246	Support	
58	194747	Boulon à épaulement	
59	194748	Rondelle	
60	73971000	Ecrou frein à coller 5/8-11	
61	194740	Barre de direction C.G.	
62	194741	Barre de direction C.D.	
64	199849	Collier de retenue	
66	71020748	Bouilon H 7/16-14 x 3	
67	194737	Douille	
68	73900700	Ecrou frein à coller 7/16-14 Cat. 5	
69	199162	Rondelle 1.5 x .505 x .118	
70	196197	Support	

REMARQUE: Toutes les dimensions de composant sont don-
nées en pouces E.-U. --1 pouce = 25,4 mm



ENSEMBLE DE LA DIRECTION
TRACTEUR - NO. DE MODÈLE PGT26H54 (96042004002), NO. DE PRODUIT 960 42 00-40

NO.	NO DE	DE PIECE	DESCRIPTION	DESCRIPTION	NO. DE	DE PIECE	DESCRIPTION	
1	-----	7070E	Transmission, Tufftrord K66	Transmission, Tufftrord K66	2	7563R	Rondelle enduite	Cle
3	199837	140080	Assemblée De Moyeu De Roue	Assemblée De Moyeu De Roue	4	1913136	19131361X505	Rondelle 13/32 x 13/16 x 16 Ga.
5	199679	407245	Ressort De frein	Ressort de rappel	6	401072	195361X505	Rondelle 3/8-16 x 2-1/2
7	171	170	194322	Guidon	8	140080	195361X505	Boulon 3/8-16 x 2-1/2
9	183	184	19133210	Ressort de retenue	10	186	194321	Ressort de retenue
11	187	188	194323	Raccord d'embarayage	12	189	194317	Levier coude
13	187	190	194318	Guide	14	196	17000616	Vis 3/8-16 x 1
15	185	185	19110620	Boulon	16	196	17000616	Couverture de la pédale
17	186	186	194321	Ressort de retenue	18	187	19133210	Couverture de stationnement
19	188	188	194323	Raccord d'embarayage	20	189	194317	Tige
21	187	190	194318	Guide	22	196	17000616	Vis 1/4 x 1/2
23	186	186	197867	Support	24	196131	193099X428	Pédale en avant
25	187	187	197868	Support pour le poulie	26	196131	193099X428	Pédale contre
27	186	186	197867	Support	27	196131	193099X428	Collier de retenue
29	187	187	197868	Support	28	197869	199466	Section de nylon
31	186	186	197867	Support	29	197860	199466	Cubiluteur
33	187	187	197867	Support	30	197869	199466	Tige
35	187	187	197868	Support	31	1201183X	1201183X	Pailier de nylon
37	186	186	197867	Support	32	195352X428	195352X428	Boulon
39	187	187	197868	Support	33	19302X428	19302X428	Pédale en avant
41	186	186	197867	Support	34	193099X428	193099X428	Collier de retenue
43	187	187	197868	Support	35	197869	199466	Section de nylon
45	186	186	197867	Support	36	197860	199466	Cubiluteur
47	187	187	197868	Support	37	197869	199466	Tige
49	186	186	197867	Support	38	197868	199466	Section de nylon
50	187	187	197868	Support	39	197869	199466	Cubiluteur
51	186	186	197867	Support	40	197868	199466	Tige
52	187	187	197868	Support	41	197869	199466	Section de nylon
54	186	186	197867	Support	42	197868	199466	Couverture de la pédale
56	187	187	197868	Support	43	197869	199466	Tige
58	186	186	197867	Support	44	197860	199466	Section de nylon
60	187	187	197868	Support	45	197869	199466	Cubiluteur
62	186	186	197867	Support	46	197868	199466	Tige
64	187	187	197868	Support	47	197869	199466	Section de nylon
66	186	186	197867	Support	48	197868	199466	Couverture de la pédale
68	187	187	197868	Support	49	197869	199466	Tige
70	186	186	197867	Support	50	194327	194327	Poulie du gâlet-tendeur
72	187	187	197868	Support	51	194327	194327	Poulie du gâlet-tendeur
74	186	186	197867	Support	52	194326	194326	Gâlet-tendeur
76	187	187	197868	Support	53	197865	197865	Ensemble trapézoïdale
78	186	186	197867	Support	54	125800X	125800X	Ensemble de l'arbre
80	187	187	197868	Support	55	74490544	74490544	Poulie Hex Fighd 5/16-18 Gr. 5
82	186	186	197867	Support	56	4072432	4072432	Ensemble trapézoïdale
84	187	187	197868	Support	57	142432	142432	Poulie de l'arbre
86	186	186	197867	Support	58	407247	407247	Boulon Hex Fighd 5/16-18 Gr. 5
88	187	187	197868	Support	59	73900500	73900500	Ecrou frein H 5/16-18
90	186	186	197867	Support	60	17000512	17000512	Saute la tige
92	187	187	197868	Support	61	1740508	1740508	Ecrou frein H 5/16-18
94	186	186	197867	Support	62	407247	407247	Attaché de fixation
96	187	187	197868	Support	63	19725	19725	Baguette en E
98	186	186	197867	Support	64	125907X	125907X	Gâlet-tendeur
100	187	187	197868	Support	65	194326	194326	Poulie de l'arbre
102	186	186	197867	Support	66	123800X	123800X	Ensemble de l'arbre
104	187	187	197868	Support	67	74490544	74490544	Poulie Hex Fighd 5/16-18 Gr. 5
106	186	186	197867	Support	68	4072432	4072432	Ensemble trapézoïdale
108	187	187	197868	Support	69	123800X	123800X	Poulie de l'arbre
110	186	186	197867	Support	70	1740508	1740508	Ecrou frein 3/8-16
112	187	187	197868	Support	71	197869	197869	Section de nylon
114	186	186	197867	Support	72	197868	197868	Coupler de retenue
116	187	187	197868	Support	73	74490544	74490544	Poulie de l'arbre
118	186	186	197867	Support	74	142432	142432	Ensemble trapézoïdale
120	187	187	197868	Support	75	197865	197865	Gâlet-tendeur
122	186	186	197867	Support	76	199679	199679	Poulie frein
124	187	187	197868	Support	77	401072	401072	Rondelle 13/32 x 13/16 x 16 Ga.
126	186	186	197867	Support	78	197869	197869	Section de nylon
128	187	187	197868	Support	79	197868	197868	Coupler de retenue
130	186	186	197867	Support	80	407247	407247	Ecrou frein 3/8-16
132	187	187	197868	Support	81	197869	197869	Section de nylon
134	186	186	197867	Support	82	197868	197868	Coupler de retenue
136	187	187	197868	Support	83	197869	197869	Section de nylon
138	186	186	197867	Support	84	197868	197868	Coupler de retenue
140	187	187	197868	Support	85	197869	197869	Section de nylon
142	186	186	197867	Support	86	197868	197868	Coupler de retenue
144	187	187	197868	Support	87	197869	197869	Section de nylon
146	186	186	197867	Support	88	197868	197868	Coupler de retenue
148	187	187	197868	Support	89	197869	197869	Section de nylon
150	186	186	197867	Support	90	197868	197868	Coupler de retenue
152	187	187	197868	Support	91	197869	197869	Section de nylon
154	186	186	197867	Support	92	197868	197868	Coupler de retenue
156	187	187	197868	Support	93	197869	197869	Section de nylon
158	186	186	197867	Support	94	197868	197868	Coupler de retenue
160	187	187	197868	Support	95	197869	197869	Section de nylon
162	186	186	197867	Support	96	197868	197868	Coupler de retenue
164	187	187	197868	Support	97	197869	197869	Section de nylon
166	186	186	197867	Support	98	197868	197868	Coupler de retenue
168	187	187	197868	Support	99	197869	197869	Section de nylon
170	186	186	197867	Support	100	197868	197868	Coupler de retenue
172	187	187	197868	Support	101	197869	197869	Section de nylon
174	186	186	197867	Support	102	197868	197868	Coupler de retenue
176	187	187	197868	Support	103	197869	197869	Section de nylon
178	186	186	197867	Support	104	197868	197868	Coupler de retenue
180	187	187	197868	Support	105	197869	197869	Section de nylon
182	186	186	197867	Support	106	197868	197868	Coupler de retenue
184	187	187	197868	Support	107	197869	197869	Section de nylon
186	186	186	197867	Support	108	197868	197868	Coupler de retenue
188	187	187	197868	Support	109	197869	197869	Section de nylon
190	186	186	197867	Support	110	197868	197868	Coupler de retenue
192	187	187	197868	Support	111	197869	197869	Section de nylon
194	186	186	197867	Support	112	197868	197868	Coupler de retenue
196	187	187	197868	Support	113	197869	197869	Section de nylon
198	186	186	197867	Support	114	197868	197868	Coupler de retenue
200	187	187	197868	Support	115	197869	197869	Section de nylon
202	186	186	197867	Support	116	197868	197868	Coupler de retenue
204	187	187	197868	Support	117	197869	197869	Section de nylon
206	186	186	197867	Support	118	197868	197868	Coupler de retenue
208	187	187	197868	Support	119	197869	197869	Section de nylon
210	186	186	197867	Support	120	197868	197868	Coupler de retenue
212	187	187	197868	Support	121	197869	197869	Section de nylon
214	186	186	197867	Support	122	197868	197868	Coupler de retenue
216	187	187	197868	Support	123	197869	197869	Section de nylon
218	186	186	197867	Support	124	197868	197868	Coupler de retenue
220	187	187	197868	Support	125	197869	197869	Section de nylon
222	186	186	197867	Support	126	197868	197868	Coupler de retenue
224	187	187	197868	Support	127	197869	197869	Section de nylon
226	186	186	197867	Support	128	197868	197868	Coupler de retenue
228	187	187	197868	Support	129	197869	197869	Section de nylon
230	186	186	197867	Support	131	197868	197868	Coupler de retenue
232	187	187	197868	Support	133	197869	197869	Section de nylon
234	186	186	197867	Support	135	197868	197868	Couverture en E
236	187	187	197868	Support	136	197869	197869	Tige du frein
238	186	186	197867	Support	137	197868	197868	Racord de l'arbre
240	187	187	197868	Support	138	197869	197869	Racord de l'arbre
242	186	186	197867	Support	139	197868	197868	Racord de l'arbre
244	187	187	197868	Support	140	197869	197869	Racord de l'arbre
246	186	186	197867	Support	141	197868	197868	Racord de l'arbre
248	187	187	197868	Support	142	197869	197869	Racord de l'arbre
250	186	186	197867	Support	143	197868	197868	Racord de l'arbre
252	187	187	197868	Support	144	197869	197869	Racord de l'arbre
254	186	186	197867	Support	145	19		




CHASSIS/ENCINTES

NO.	NO	DE	PIECE	REF.	DESCRIPTION
5	195102X428	Tableau de bord			
14	175260X420	Capot			
18	175289X428	Calandre			
34	196125	Plaque de la moteur			
36	17060512	Screw 5/16-18 x 3/4			
37	400009X428	Allie			
58	1740508	Support			
68	174314				
122	192512	Vis 10-13 x 5/8			
130	191611	Vis H 10 x 3/4			
148	164655	Boulon			
150	175351	Bouton			
152	199535	Deflecteur			
153	161840	Barre D'Objetif			
161	193097X428	Fenêtre de combustible			
162	142432	Vis H 1/4 x 1/2			
165	196826	Soutien du support			
175	193236	Pièce d'entretien			
176	400776	Vis 10-24 x 5/8			
177	195227	Douille			
178	195651	Couverture			
180	195477	Chassis			
181	193102X428	Douille			
183	74780520	Boulon			
189	17000512	Vis 5/16-18 x 3/4			
194	73900500	Ecrou frein H 5/16-18			
196	193098X428	Panneau du tableau de bord			
198	197090X505	Indicateur D'ascenseur De Plate-forme			
199	196377	Plaque de renforcement			
205	169847X428	Jupes C.D.			
206	169848X428	Jupes C.G.			
222	137729	Vis 1/4-20 x 5/8			
228	195161	Attache De Goujon			
235	406129	Entretiise			
236	73930500	Ecrou			
278	196394	Support, Capot			


REMARQUE: Toutes les dimensions de composant sont données en pouces E.-U. -1 pouce = 25,4 mm

chassis-tex_Stealth II PL_1






NO.	DE	PIÈCE	DESCRIPTION
1	144927	Batterie	Bouillon H 1/4-20 unc x 3/4
2	74760412	Batterie	Bouillon H 1/4-20 unc x 3/4
8	176491	Bac de batterie	Bac de batterie
16	176138	Amouple	Interrupteur de verrouillage presse
21	175688	Amouple	Harnais des preses de courant des phares W/141521
22	4152	Câble de batterie	Câble de batterie de 6 ja avec un fil de 16 po. - rouge
24	400253	Câble de batterie	Câble de batterie de 6 ja avec un fil de 16 po. - noir
25	198893	Fusible	Fusible
26	175158	Ecrou H 1/4-20 unc	Ecrou H 1/4-20 unc
27	73510400	Câble de masse	Câble de masse de 6 ja. de 21" - noir
28	145491	Interrupteur	Interrupteur
29	401545	Câble de masse	Câble de masse de 6 ja. de 21" - noir
30	193350	Connacleur d'alumage	Connacleur d'alumage
33	411935	Cle de contact	Cle de contact
34	110712X	Support	Support
40	401104	Couverture de borne	Interrupteur des phares
41	17720408	Vis 1/4-20 x 1/2	Vis 1/4-20 x 1/2
42	131563	Couverture de borne	Couverture de borne
43	192507	Solenoïde	Solenoïde
46	401763	Compteur horaire	Compteur horaire
50	174653	Interrupteur	Interrupteur
55	17060512	Vis 5/16-18 x 3/4	Vis 5/16-18 x 3/4
59	400303	Sortie 12-Volt	Sortie 12-Volt
71	194276	Harnais des câbles d'allumage Chassis	Harnais des câbles d'allumage Chassis
79	175242	Assembly De Bulbholder	Assembly De Bulbholder
90	400724	Couverture	Couverture
91	190270	Attache	Attache
99	17670412	Vis H 1/4-20 x 3/4	Vis H 1/4-20 x 3/4
100	19091416	Rondelle 9/32 x 7/8 x 16 ja.	Rondelle 9/32 x 7/8 x 16 ja.
101	198317	Natte MATNLK	Natte MATNLK
102	404454	Exploiter la natté 12V sortie	Exploiter la natté 12V sortie
103	407962	Exploiter la natté K46	Exploiter la natté K46

REMARQUE: Toutes les dimensions de composant sont don- nées en pouces E.-U. --1 pouce = 25,4 mm




CONTACTEUR D'ALLUMAGE




REMARQUE: Toutes les dimensions de composant sont données en pouces E.-U. -- 1 pouce = 25,4 mm

2



WHEELS AND TIRES

NO.	NO	REF	PIECE	DESCRIPTION
1	411658	411140	DECALCOMANIE D'OPÉRATION	Decalcomanie du capot avec
2	402355	402525	DECALCOMANIE INFERIEUR TABLEAU DE BORD	Decalcomanie inférieur tableau de bord
3	172743	172740	DECALCOMANIE VOLANT DE RECHANGÉ	Decalcomanie volant de rechancage
4	172743	172740	DECALCOMANIE DE PIÈCES DE RECHANGÉ	Decalcomanie de pièces de rechancage
5	408843	408948	DECALCOMANIE LATÉRALE	Decalcomanie latérale
6	198785	166960	DECALCOMANIE DU MOTEUR	Decalcomanie du moteur
7	145005	193279428	DECALCOMANIE DE TONDUEUSE	Decalcomanie de tondueuse
8	198785	193101X428	COUSSIN DRÔPOSE-PIED C.G.	Coussin drôpose-pied C.G.
9	402357	409631	DECALCOMANIE DU CAPOT AVANT	Decalcomanie du capot avec
10	402357	417307	MANUEL DU PROPRÉTAIRE (FRANÇAIS)	Manuel du propriétaire (français)



DECALCOMANIE

TRACTEUR - NO. DE MODÈLE PBT26H54 (96042004002), NO. DE PRODUIT 960 42 00-40


Visitez notre site web: www.poulan-pro.com

Portez toujours des lunettes de sécurité lors de l'utilisation.

PBGT26H54

MODÈLE:

MANUEL DE PARTIES DE RÉPARATION



Poulan Pro

NE JETEZ PAS

MANUEL IMPORTANT